

Wheel Spacers and Locknuts



WHEELS SPACERS & LUGS

1. CW16 Pair of wheel spacers with studs 1" (25mm wide).
2. CW15 Pair of wheel spacers with studs 3/4" (19mm wide).
3. CW1 Pair of wheel spacers with studs 3/8" (10mm wide).
- 4a. SR4 Pair of wheel spacer shims (5mm wide).
- b. SR3 Pair of wheel spacer shims (3mm wide).
5. Wheel stud length starts from shoulder to end, not end to end.

2112064	Stud length 35mm with thread length 22mm.
21A2064L	Stud length 50mm with thread length 23mm.
NAM5645	Stud length 32mm with thread length 23mm.
21A1278	Stud length 55mm with thread length 20mm.
ENJO-1039	Stud length 58mm with thread length 19mm.
ENJO-1040	Stud length 75mm with thread length 27mm.
6. LOCKNUT 1 4 locking nuts for latest Mini/Cooper 8 spoke Alloy.
 LOCKNUT 2 4 locking nuts for Mamba/Revo 10" wheels.
 LOCKNUT 3 4 locking nuts for Mini/Original Minilite wheel pre 1980.
 LOCKNUT 4 4 locking nuts for 13" RFX/Phoenix/Superlite large radius seat CN5 nut.
 LOCKNUT 5 4 locking nuts, Mini steel - 84 on, Wella CN2-type.
 LOCKNUT 6 4 locking nuts, Mini steel - pre 1984. GB alloys CN1/2 type.
7. CN1 #6 Chrome long nut, equiv. type fitted to Mini steel whls to 1984, round radius bottom.
 CN1A Lrg. seat # 6 Chrome long nut for round seat per steel wheel pre '84. Can be used for CN1 if req'd.
 CN2 #5 Chrome long nut, equiv. to type fitted to all steel whls. from '84, 60 degree angle bottom. Fits Wella and Minator.
 CN5 Large seat #5 Chrome long nut fits Superlite, Revo RFX 6x13 or any whls. w/ 60 degree deep seat for nut.
8. C-21A1969 Sieve nut and chamfered washer in stainless steel for Minilite.
 CN3 Chrome sleeve nut and flat washer for Wolftrace/Slot Mag/Old Minilite.
 REV09 Sieve nut in stainless steel for Mamba/Revolution with washer.

Bonnet



BONNET and BODY ACCESSORIES

1. MSSK019 Quick release bonnet hinges for standard metal bonnet. Pair of mk3 bonnet hinges made for removing the whole bonnet for engine work.
2. GS130273 Internal release bonnet lock. The kit includes a new catch with bolts, correct length cable and bracket to fit at the end of the parcel shelf. (not clubman)
3. MSSK018 Spring loaded bracket bolts to original hinge as safe auxiliary bonnet prop.
4. RS17 Front plastic spoiler for Mini, about 6.5" deep.
 4a. RS18 Front plastic spoiler for Mini Clubman, about 6.5" deep.
5. EBF100150 Plastic boot load liner sturdy, lightweight and easily removable. Tailor made for cars from 1974 on with larger 7.5 gallon petrol tanks.
6. MSA1118 Antenna. Wing mounting telescopic aerial, budget replacement
 6a. MSA1119 Antenna. Roof aerial for the 60's look

Body Accessories

