


FRONT INDICATOR & PARK LAMPS



FRONT LAMPS

NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	189100	Flasher and park lamp assy with clear glass lens	2	
1	189100MS	Flasher and park lamp assy with clear plastic lens	2	
1	189101	Flasher and park lamp assy with amber glass lens	2	
2	37H5527	Rubber body seal	2	
3	572734	Chrome rim	2	
4	37H8130	Amber lens plastic	2	
4	54581651	Amber lens glass	2	
4	54581622	Clear lens glass	2	
4	54581622/P	Clear lens plastic	2	
4	576109	Red glass lens	4	Moke
5	37H5228	Single filament bulb holder (indicator only)	2	
5	27H5545	Double filament bulb holder (side and indicator 189100)	2	Not UK
6	1073	Bulb, flasher, single element	2	
7	1157	Bulb, dual element	2	Not UK
8	GHF421	Fixing screw	6	
9	GHF771	Fixing clip	6	
10	575457A	Lamp (Europe)	2	NLA
11	37H6111	Front lens, Europe, Canada	2	
12	AFL3389	Orange indicator lamp	2	1987 on
13	CDU3374	Lens	2	1987 on
14	ADU3017	Clubman front indicator lamp L/RH	1	
14	ADU3018	Clubman front indicator lamp R/LH	1	
15	BAU1796	Lens, park and indicator lens with seal	2	
16	37H4190	Seal - lens to body	2	NLA
17	GLR233	Sidelamp bulb	2	
18	1073	Flasher bulb	2	
19	AAL3296	Wing side repeater lamp	2	1979-80 only
20	27H2403	Lens for AAL3296	2	
21	GLB989	Bulb	2	
22	AHU2592	Wing side repeater lamp	2	1986 on
23	DCP8004	Bulb holder	2	
24	AFL1112	Bulb holder sealing ring	2	
25	GLB501	Bulb	2	
26	LMP114	Front lamp assembly, Moke, all white lens	2	
	LMP171	Front lens, Moke, amber/white	2	